

## LUXURY ARM ATTACHMENT INSTRUCTIONS



### Tools needed:

- Drill
- Drill Bits
- Philips Screwdriver Bit

### STEP ONE

Determine which end of the lounge the arm would attach to. Make sure the correct arm is on the correct end of the lounge (Cup holders will be forward). On the end that is intended to have an arm, drill hole in the four corners about 1" with either a drill or hole saw. Be sure to ONLY drill thru the inner wall. Enter through the holes, which were just drilled, and start a pilot hole in each hole. These pilot holes will serve as guides for getting the screws started. Be sure to use a very small drill bit, smaller than the screw, for the pilot holes. Attach the arm with the screws using the pilot holes for help. Next, align the arm flush with the back of the seat. Hand tighten until all screws are snug, DO NOT OVER TIGHTEN!

