

PLATINUM & PREMIUM ARM ATTACHMENT INSTRUCTIONS



Tools needed:

- Drill
- Drill bit
- Philips screwdriver bit

NOTE: This instruction sheet is a drilling template.

STEP ONE

Attaching arm/s consists of two separate steps. Reference Illustration Below to identify which is right and left side. Starting with the left side align sheet flush to the front and top of the base (follow arrows); tape securely. Drill out the four holes with the appropriate sized bit (according to the fasteners you choose) Drill through base only. After completed, repeat step one if a right side application is used. (Utilize the holes you cut in the template when drilling the left side, for the right side also).

STEP TWO

Using screws that freely go through the holes you've just drilled in the base, align rear of arm so that it is flush with rear and left side of the base. While attaching arm to base, make sure both components are held together tightly. (Hand tighten until all screws are snug) **DO NOT OVER TIGHTEN!**

