

## BIMINI | HELPFUL HINTS

### Bimini All-around Light (Anchor Light)

Are you going to put your All-around (Anchor) Light on top of your bimini?

- On a new bimini, thread 2 wires through the rear bow (usually on the right side) to the center of the top bow when you assemble the bimini frame. \*
- Drill a ¼" exit hole for the wire from inside the frame. Protect the wire from sharp edges with a grommet or electrical tape.
- Install a folding All-around Light (Part Number 23-5358127 on the electrical page).
- We suggest that you use a plug (Part Number 50-13841) at the hinge point of the bimini at the rail to simplify removal of the bimini.

*\* To identify left and right on a pontoon, face the direction of travel. In boating terms, left is "port," right is "starboard."*